

SERIAL NUMBER IDENTIFICATION GUIDE: SUPERMICRO SERVERS

1. SERVERS 1U:

1.1 Proceed to the Supermicro chassis.



Figure 1 – Front Panel

1.2 Locate the rear panel of the Supermicro chassis.



Figure 2 – Rear Panel – Full View

1.3 Locate the label with the serial number located on the rear panel of the chassis.




Figure 3 – Rear Panel – Serial Number

2. SERVERS 2U:

2.1 Proceed to the front panel of the Supermicro chassis.



Figure 4 – Front Panel

2.2 You will see a small removable plate on the left side, which will show a small label containing the serial number of the Supermicro chassis.




Figure 5 – Front Panel – Removable Plate



Figure 6 – Front Panel – Serial Number